

CASH® Magnum FreeFlight

Spare parts list and diagram



©2018 Frontmatec Accles & Shelvoke Ltd




DO NOT ATTEMPT TO USE THESE STUNNING TOOLS UNTIL
YOU HAVE READ AND UNDERSTOOD THE USER MANUAL

ONLY EVER USE GENUINE ACCLES & SHELVOKE REPLACEMENT PARTS. NOT USING GENUINE PARTS MAY LEAD TO PREMATURE COMPONENT AND TOOL FAILURE, WHICH COULD ENDANGER THE OPERATOR AND THOSE IN THE IMMEDIATE VICINITY. IT WILL ALSO INVALIDATE OUR ORIGINAL EQUIPMENT WARRANTY.

ACCLES & SHELVOKE WILL ACCEPT NO LIABILITY IF ANY COMPONENTS OTHER THAN THOSE SUPPLIED BY ACCLES & SHELVOKE ARE USED WITH OUR ORIGINAL EQUIPMENT. THE RESULTANT LIABILITY WILL BE WITH THE END USER OR THE DISTRIBUTOR WHO SUPPLIED THE UNAPPROVED REPLACEMENT PARTS.

FIG. 11.01



©2018 Accles & Shelvoke

Item no.	Part description	Qty per set	SPARE PART BY PRODUCT CODE		
			5648	5648R	5648RNS
1	Barrel	1		5708	
2	Buffer hard black	2		5621	
3	Buffer soft red	1		5632	
4	Bolt	1		5623	
5	Breech	1	5624HD		5624R
6	Breech cap	1		5707	
7	Collar retaining pin	1		5726	
8	Small O-ring	1		5627	
9	Trigger spring	1		5628	
10	Firing pin spring	1		5755	
11	Pull	1		5702	
12	Cap inner	1		5693	N/A
13	O-ring	1		5695	N/A
14	Stop fire cap	1		5692	N/A
15	Stop pin	1		3036	N/A
16	Stop fire assembly (complete)	1		5691	N/A
17	Firing pin	1		5690	
18	Trigger	1		5689	
18A	Extractor plunger	1		5636	
19	Lock washer	1		5639	
20	Pull bush	1		5640	
21	Pull split bush (pair)	1		5641	
22	Pull lock O-ring	1		5642	
23	Pull spring	1		5710	
24	Breech locking cover	1		5664	
25	Collar spring	1		5631	
26	Ball	1		3042	
27	Collar	1		5622	
28	Spring cap	1		N/A	5696