

CASH® Magnum Concussion

Spare parts list and diagram



©2018 Frontmatec Accles & Shelvoke Ltd




DO NOT ATTEMPT TO USE THESE STUNNING TOOLS UNTIL
YOU HAVE READ AND UNDERSTOOD THE USER MANUAL

ONLY EVER USE GENUINE ACCLES & SHELVOKE REPLACEMENT PARTS. NOT USING GENUINE PARTS MAY LEAD TO PREMATURE COMPONENT AND TOOL FAILURE, WHICH COULD ENDANGER THE OPERATOR AND THOSE IN THE IMMEDIATE VICINITY. IT WILL ALSO INVALIDATE OUR ORIGINAL EQUIPMENT WARRANTY.

ACCLES & SHELVOKE WILL ACCEPT NO LIABILITY IF ANY COMPONENTS OTHER THAN THOSE SUPPLIED BY ACCLES & SHELVOKE ARE USED WITH OUR ORIGINAL EQUIPMENT. THE RESULTANT LIABILITY WILL BE WITH THE END USER OR THE DISTRIBUTOR WHO SUPPLIED THE UNAPPROVED REPLACEMENT PARTS.

FIG. 11.01



©2018 Accles & Shelvoke

Item no.	Part description	Qty per set	SPARE PART BY PRODUCT CODE			
			5654 .25	5654AS .25	5654R .25	5654RS .25
1	Muzzle	1	5680			
2	Split buffer	1	5668/A			
3	Bolt	1	5670			
4	Packing ring	1	5669			
5	Thrust collar (pairs)	1	5667			
6	Lock washer	1	4115			
7	Retaining ring	1	5658			
8	Ball	3	3042			
9	Breech	1	5665		5665R	
10	Breech cap	1	5707			
11	Small O-ring	1	5627			
12	Trigger spring	1	5628			
13	Firing pin spring	1	5755			
14	Pull	1	5702			
15	Cap inner	1	N/A	5693	N/A	5693
16	O-ring	1	N/A	5695	N/A	5695
17	Stop fire cap	1	N/A	5692	N/A	5692
18	Stop pin	1	N/A	3036	N/A	3036
18A	Stop fire assembly (complete)	1	N/A	5691	N/A	5691
19	Firing pin	1	5690			
20	Trigger	1	5689			
21	Extractor plunger	1	5636			
22	Plunger spring	1	5637			
23	Extractor	1	5638			
24	Pull bush	1	5640			
25	Pull split bush (pair)	1	5641			
26	Pull lock O-ring	1	5642			
27	Pull spring	1	5710			
28	Breech locking cover	1	5664			
29	Spring cap	1	5696	N/A	5696	N/A